

RESET

< Previous instruction: [RCALL](#) | Instruction [index](#) | Next instruction: [RETFIE](#) >

RESET	Reset				
Syntax:	[<i>label</i>] RESET				
Operands:	None				
Operation:	Reset all registers and flags that are affected by a <u>MCLR</u> Reset.				
Status Affected:	All				
Encoding:	<table><tr><td>0000</td><td>0000</td><td>1111</td><td>1111</td></tr></table>	0000	0000	1111	1111
0000	0000	1111	1111		
Description:	This instruction provides a way to execute a <u>MCLR</u> Reset in software.				
Words:	1				
Cycles:	1				
Q Cycle Activity:					
Q1	Q2	Q3	Q4		
Decode	Start reset	No operation	No operation		

Example: RESET

After Instruction

Registers = Reset Value
Flags* = Reset Value

< Previous instruction: [RCALL](#) | Instruction [index](#) | Next instruction: [RETFIE](#) >